

YDUN 5.5

SCOUT TENT

Product book

CONGRATULATIONS!

We wish you lots of fun with your new Nordisk Cotton tent

GLÜCKWUNSCH

TILLYKKE!

FÉLICITATIONS

おめでとうございます

GEFELICITEERD!

GRATULACJE

축하

祝賀

TOPPOISK

LOVES YOU


BUILD UP INSTRUCTION

1

Spread out the tent and loosely attach a few straps to the ground using the tent pegs. Loosen all guy ropes before you head to the next steps.




Ensure an even surface without any sharp objects!



YDUN 5.5

2

Open the entrance and place the pole in the entrance section. The peak of it needs to be pushed through the eyelet at the roof of entrance. When erected the bottom of the pole must be placed at the reinforced spot of the ground. Use one guy rope to fix it.



13

Repeat step 2 with the second pole on the other side. Then close the entrance again. Go on with the 4 poles which fits at bottom of each window to give down force. These are loose and can be inserted from a button hole on the back of the lower seam.




4

Finally use the pegs and ropes to attach the tent to the ground and anchor sufficiently. Ensure the doors are closed before erecting the tent to ensure correct tension.


A

If you have the matching cabin for your Nordisk Ydun, you can now attach this inside. Find the coloured connection point which indicates where to connect your inner cabin to the tent. Attach the buckle followed by the remaining





Ydun has a certain "front" door which can be zipped off at bottom and floor can be extended out flat and pegged to the ground for easy entry/exit or cleaning





TAKE CARE OF YOUR NORDISK COTTON TENT

Before Trek

- · build up the tent from home and check if everything is ok.
- · know the environment you'll go to (sand, hard soil, snow), and check that pegs etc. matches this
- · check that the poles are ok, and if not; buy a new set before you go
- · make sure the tent is clean
- ensure that **zippers runs smoothly** (if not, get some zipper spray)





In the Camp

- · make sure you pitch on an even and big enough surface
- · remove sharp rocks and sticks that could harm the tent floor
- · stretch the tent as much as possible for optimal strength and water repellency
- · if wet or very windy, you need to re-adjust the tension of the guy ropes
- · if very windy, use extra guy ropes and pegs for stability
- · put the packsack somewhere where you can find it again
- · avoid fire and smoke near the tent be aware of wind directions!
- · keep an eye on **guy rope tension** once in a while
- · remove all traces from your camp

Ting S. Tricke

Living with your tent

- do not use any sort of coating a clean cotton tent has the best water repellency
- · keep it clean with a soft sponge or brush
- · use no harsh chemical cleaning or machine washing
- **keep it dry**, and if packed down wet, remember to dry it as soon as possible remember that a wet tent is heavier than a dry one
- · store in dry surroundings
- · check guy ropes and pegs once in a while, and buy new ones if damaged
- · if you have damaged poles, your local Nordisk dealer can supply new ones
- · be aware that long exposure of sunlight can degrade the fabric
- · love and nurse your tent. If you protect your tent, it will protect you

You can find more information on nordisk.eu

Tips & Tricks

- 1 Do not coat your cotton tent with anything keep the cotton fabric as it is
- 2 Put rain caps on the poles when it's raining
- 3 Installing the inner cabin can give you an even better climate
- 4 The windows in the sides can open, with or without mosquito net
- 5 Use the mosquito net in the doors to enjoy the view in the evening
- **6** Adjust the center pole to increase or decrease tension on the tent



Scan it!

For 360° View, Windtest, How to pitch & Fact sheet



Download app:

From the AppStore:

Nordisktents



LEGACY ORIGINAL SPARE PARTS

Makes your Nordisk Cotton tent last longer...



Guy rope, 5,0 mm, 20 meter Item no.: 119048



Guy rope, 3,5 mm, 20 meter Item no.: 800



Guy rope, 5,0 mm, 20 meter Item no.: 801



Nylon webbing with ladder lock Item no.: 802



Adhesive fabric patch Item no.: 803 Technical cotton 804 Green cotton



Fabric roll, 10 meter Item no.: 840 Technical cotton 841 Green cotton



Zipper p uller Item no.: 806



Cord stopper

Spare parts available!



Mosquito mesh, 10 meter Item no.: 807



Velcro for zipper flaps and door Item no.: 809



Full cover rain cap Item no.: 810



Rubber part for center pole Item no.: 811-813



YKK zipper slider with puller Item no.: 814



Webbing loop for A frame Item no.: 815



8-hook for inner tent Item no.: 816



Triangular slider Item no.: 119045



Alu. hook for inner tent Item no.: 819



Ventilation hook

Item no.: 805

LEGACY ORIGINAL SPARE PARTS

Makes your Nordisk Cotton tent last longer...



Fly sheet pack sac

Pole bag

Item no.: 818



Tarp packsack Item no.: 828 - Kari 12m2



Peg b ag Item no.: 817





Inner tent packsack Item no.: M - 842 L-843



Zip-in floor bag Item no.: S - 824 M - 825 L-826



Compression webbing for poles Item no.:820



Compression webbing for tents Item no.: 822 - 25mm 823 - 38mm





Steel V-peg Extreme hold and grip Item no.: 119039



Steel T peg Extreme strong T shape Item no.: 119037



Steel nail Extreme grip and superior strength Item no.: 119040



Contact your local Dealer



www.nordisk.eu

Nordisk International

Papirfabrikken 74 DK-8600 Silkeborg Tel. +45 7373 4000 Fax +45 7373 8015 info@nordisk.eu

Nordisk Germany

Max-Weber-Strasse 16 D-25451 Quickborn Tel. +49 (0) 4106 76770 Fax +49 (0) 4106 767714 info@nordisk.de

Denmark, International

Germany, Austria, Switzerland